


Artikelnr. Item no.	Produkt Product
55433	InScenio 230
54978	InScenio FM-Master 1
36310	InScenio FM-Master 2
36311	InScenio FM-Master 3
56886	InScenio FM-Profimaster
55860	FR InScenio 230
55856	FR InScenio FM-Master 1
55858	FR InScenio FM-Master 2
55859	FR InScenio FM-Master 3
56473	GB InScenio FM-Master 3



Artikelnr. Produkt Item no. Product	Pos. Pos.	Artikelnr. Ersatzteil Item no. Spare part	VE PU	Ersatzteil	Spare part
55433	1	33371	1	Haube FM-Master	Cover FM-Master
	4	20284	1	Erdspieß	Spike
36310	1	33371	1	Haube FM-Master	Cover FM-Master
	4	20284	1	Erdspieß	Spike
	5	14496	1	Einlernstift FM-Master	Teach-in pin FM-Master
	7	22653	1	Handsender FM-Master	Remote control FM-Master
36311	1	33371	1	Haube FM-Master	Cover FM-Master
	2	14368	1	G-Feinsicherung träge 2,0 A	Fuse T 2.0 A
	3	27645	1	Ersatz Feinsicherungshalter FM-Master 3	Spare fuse holder FM-Master 3
	4	20284	1	Erdspieß	Spike
	5	14496	1	Einlernstift FM-Master	Teach-in pin FM-Master
	7	22653	1	Handsender FM-Master	Remote control FM-Master
54978	1	33371	1	Haube FM-Master	Cover FM-Master
	4	20284	1	Erdspieß	Spike
	5	14496	1	Einlernstift FM-Master	Teach-in pin FM-Master
	7	22653	1	Handsender FM-Master	Remote control FM-Master
56886	1	33371	1	Haube FM-Master	Cover FM-Master
	2	14368	1	G-Feinsicherung träge 2,0 A	Fuse T 2.0 A
	3	27645	1	Ersatz Feinsicherungshalter FM-Master 3	Spare fuse holder FM-Master 3
	4	20284	1	Erdspieß	Spike
	5	14496	1	Einlernstift FM-Master	Teach-in pin FM-Master
	7	22653	1	Handsender FM-Master	Remote control FM-Master
55860	1	33371	1	Haube FM-Master	Cover FM-Master
	4	20284	1	Erdspieß	Spike
55856	1	33371	1	Haube FM-Master	Cover FM-Master
	4	20284	1	Erdspieß	Spike
	5	14496	1	Einlernstift FM-Master	Teach-in pin FM-Master
	7	22653	1	Handsender FM-Master	Remote control FM-Master
55858	1	33371	1	Haube FM-Master	Cover FM-Master
	4	20284	1	Erdspieß	Spike
	5	14496	1	Einlernstift FM-Master	Teach-in pin FM-Master
	7	22653	1	Handsender FM-Master	Remote control FM-Master
55859	1	33371	1	Haube FM-Master	Cover FM-Master
	2	14368	1	G-Feinsicherung träge 2,0 A	Fuse T 2.0 A
	3	27645	1	Ersatz Feinsicherungshalter FM-Master 3	Spare fuse holder FM-Master 3
	4	20284	1	Erdspieß	Spike
	5	14496	1	Einlernstift FM-Master	Teach-in pin FM-Master
	7	22653	1	Handsender FM-Master	Remote control FM-Master
56473	1	33371	1	Haube FM-Master	Cover FM-Master
	2	14368	1	G-Feinsicherung träge 2,0 A	Fuse T 2.0 A
	3	27645	1	Ersatz Feinsicherungshalter FM-Master 3	Spare fuse holder FM-Master 3
	4	20284	1	Erdspieß	Spike
	5	14496	1	Einlernstift FM-Master	Teach-in pin FM-Master
	7	22653	1	Handsender FM-Master	Remote control FM-Master